

User Guide PRD-08391

CGD15SG00D2 Gate Driver User Guide





User Guide PRD-08391

CGD15SG00D2 Gate Driver User Guide

Contents

1. Introduction	8
2. Comparison of CRD-001 and CGD15SG00D2 Gate Driver Boards	8
3. Block Diagram	9
4. Physical Dimensions	11
5. Electrical Connection Points	11
6. Schematic Drawing	12
7. Bill of Materials	12
8. PCB Layout	14
9. Revision History	15
10. Appendix	16
11. Important Notes	17



This document is prepared as a user guide to install and operate Wolfspeed® evaluation hardware. All parts of this user guide are provided in English, and the cautions are provided in English, Mandarin, and Japanese. If the end user of this board is not fluent in any of these languages, it is your responsibility to ensure that they understand the terms and conditions described in this document, including without limitation the hazards of and safe operating conditions for this board.

本文件中的所有内容均以英文书写,"注意"部分的内容以英文、中文和日语书写。作为本板子的终端用户,即使您不熟悉上述任何一种语言,您也应当确保正确理解本文件中的条款与条件,包括且不限于本板子的危险隐患以及安全操作条款。

当書類のすべての内容は英語で書きます。「注意点」の内容は英語、中国語、また日本語で書きます。当ボードの端末使用者は上記の言語が一つでもわからないなら、当端末使用者は当書類の条約と 条件が理解できるのを確保すべきです。そして、当ボードの危険や安全に使用する条件を含み、また 限りません。

Note: This Wolfspeed-designed evaluation hardware for Wolfspeed® components is a fragile, high voltage, high-temperature power electronics system that is meant to be used as an evaluation tool in a lab setting and to be handled and operated by highly qualified technicians or engineers. When this hardware is not in use, it should be stored in an area that has a storage temperature ranging from -40° Celsius to 105° Celsius. If this hardware is transported, special care should be taken during transportation to avoid damaging the board or its fragile components and the board should be transported carefully in an electrostatic discharge (ESD) bag, or with ESD or shorting protection that is the same as, or similar to, the protection that is or would be used by Wolfspeed when shipping this hardware, to avoid any damage to electronic components. Please contact Wolfspeed at *forum.wolfspeed.com* if you have any questions about the protection of this hardware during transportation. The hardware does not contain any hazardous substances, is not designed to meet any industrial, technical, or safety standards or classifications, and is not a production-qualified assembly.

本样机(易碎、高压、高温电力电子系统)由科锐为评估其功率半导体产品而设计,用以作为在实验室环境下由专业的技术人员或工程师处理和使用的评估工具。本样机不使用时,应存储在-40℃~105℃温度范围的区域内;如需运输样机,运输过程中应该特别小心,避免损坏电路板等易碎组件。如果您对此硬件在运输之中的保护有任何疑问,请联系forum.wolfspeed.com。 样机应放置在防静电包装袋内谨慎运输,避免损坏电子组件。本样机不含任何有害物质,但其设计不符合任何工业、技术或安全标准或分类,也不是可用于生产的组件。

このクリーのコンポーネント用評価ハードウェアは壊れやすい高電圧の高温パワーエレクトロニクスシステムであり、ラボ環境での評価ツールとして使用され、優秀な技術者やエンジニアによって処理され、操作されることを意図している。ハードウェアが使用されていない場合、保管温度が-40℃から105℃の範囲に保管してください。このハードウェアを輸送する場合は、輸送中にボードまたはその壊れやすいコンポーネントに損傷を与えないよう特別な注意を払う必要がある。また電子部品の損傷を避けるためにボードを静電気放電(ESD)袋に静置して慎重に輸送するべき。ハードウエアの輸送中の保護について質問があれば

https://forum.wolfspeed.com/ に連絡してください。ハードウェアには危険物質が含まれていないが、工業的、技術的、安全性の基準または分類に適合するように設計されておらず、生産適格組立品でもない。





CAUTION

PLEASE CAREFULLY REVIEW THE FOLLOWING PAGE, AS IT CONTAINS IMPORTANT INFORMATION REGARDING THE HAZARDS AND SAFE OPERATING REQUIREMENTS RELATED TO THE HANDLING AND USE OF THIS BOARD.

警告

请认真阅读以下内容,因为其中包含了处理和使用本板子有关的危险和安全操作要求方面的重要信息。

警告

ボードの使用、危険の対応、そして安全に操作する要求などの大切な情報を含むので、以下の内容をよく読んでください。





CAUTION

DO NOT TOUCH THE BOARD WHEN IT IS ENERGIZED AND ALLOW THE BULK CAPACITORS TO COMPLETELY DISCHARGE PRIOR TO HANDLING THE BOARD. THERE CAN BE VERY HIGH VOLTAGES PRESENT ON THIS EVALUATION BOARD WHEN CONNECTED TO AN ELECTRICAL SOURCE, AND SOME COMPONENTS ON THIS BOARD CAN REACH TEMPERATURES ABOVE 50° CELSIUS. FURTHER, THESE CONDITIONS WILL CONTINUE FOR A SHORT TIME AFTER THE ELECTRICAL SOURCE IS DISCONNECTED UNTIL THE BULK CAPACITORS ARE FULLY DISCHARGED.

Please ensure that appropriate safety procedures are followed when operating this board, as any of the following can occur if you handle or use this board without following proper safety precautions:

- Death
- Serious injury
- Electrocution
- Electrical shock
- Electrical burns
- Severe heat burns

You must read this document in its entirety before operating this board. It is not necessary for you to touch the board while it is energized. All test and measurement probes or attachments must be attached before the board is energized. You must never leave this board unattended or handle it when energized, and you must always ensure that all bulk capacitors have completely discharged prior to handling the board. Do not change the devices to be tested until the board is disconnected from the electrical source and the bulk capacitors have fully discharged.



警告

请勿在通电情况下接触板子,在处理板子前应使大容量电容器完全释放电力。接通电源后,该评估板上 可能存在非常高的电压,板子上一些组件的温度可能超过50 摄氏度。此外,移除电源后,上述情况可能 会短暂持续,直至大容量电容器完全释放电量。

操作板子时应确保遵守正确的安全规程,否则可能会出现下列危险:

- 死亡
- 严重伤害
- 触电
- 电击
- 电**灼**伤
- 严重的热烧伤

请在操作本**板子**前完整阅读本**文件。**通电时不必接触板子。在为板子通电**前必**须连接**所有**测试与测量探针或附件。通电时,禁止使板子处于无人看护状态,或操作板子。必须确保在操作板子前,大容量电容器解放**了所有**电量。只有在切断板子电源,且大容量电容器完全放电后,才可更换待测试器件



警告

通電している時、ボードに接触するのは禁止です。ボードを処分する前に、大容量のコンデンサーで電力を完全に釈放すべきです。通電してから、ボードにひどく高い電圧が存在している可能性があります。ボードのモジュールの温度は50 度以上になるかもしれません。また、電源を切った後、上記の状況がしばらく持続する可能性がありますので、大容量のコンデンサーで電力を完全に釈放するまで待ってください。

ボードを操作するとき、正確な安全ルールを守るのを確保すべきです。さもないと、以下の危険がある可能性があります:

- 死亡
- 重症
- 感電
- 電気の火傷
- 厳しい火傷

当ボードを操作する前に、完全に当書類をよく読んでください。通電している時にボードに接触する 必要がありません。通電する前に必ずすべての試験用のプローブあるいはアクセサリーをつないでく ださい。通電している時に無人監視やボードを操作するのは禁止です。ボードを操作する前に、大容 量のコンデンサーで電力を完全に釈放するのを必ず確保してください。ボードの電源を切った後、ま た大容量のコンデンサーで電力を完全に釈放した後、試験設備を取り換えることができます。



1. Introduction

The purpose of this user guide is to demonstrate the design and use of Wolfspeed's CGD15SG00D2 isolated single-channel gate driver tailored for Wolfspeed's 3rd Generation (C3M[™]) Silicon Carbide (SiC) MOSFETs. This design includes following features:

- Creepage-enhancing groove between the logic side and the power side of the printed circuit board (PCB)
- 2W isolated power supply that enables the operation of larger MOSFETs at higher frequencies
- 5000VAC isolation rated optocoupler
- Separate gate turn-on and gate turn-off resistors with a dedicated diode, which allows user-friendly
 optimization of both turn-on and turn-off signals
- Common mode inductor on logic power input for enhanced electro-magnetic interference (EMI) immunity
- 9mm creepage-enhancing slot between primary and secondary circuits

The top and bottom views of Wolfspeed's CGD15SG00D2 gate driver board for generation 3 SiC MOSFETs are shown in Figure 1 and Figure 2. The creepage-enhancing groove can be seen on both figures. The turn-on and turn-off resistors and the accompanying diode are all on the top side of the board to facilitate changes on the laboratory bench.




Figure 1: Top view of the board




Figure 2: Bottom view of the board

2. Comparison of CRD-001 and CGD15SG00D2 Gate Driver Boards


Since gate to source voltage (VGS) requirements of a Wolfspeed generation 3 SiC MOSFET are different from the VGS requirements of a Wolfspeed C2M[™] or a Wolfspeed CMF SiC MOSFET, CGD15SG00D2 has several features



that are different from the previously developed generation of gate driver board (Wolfspeed Part Number: CRD-001) as shown in Table 1 and Figure 3.

Table 1: Comparison of Wolfspeed's CRD-001 and CGD15SG00D2

CRD-001	CGD15SG00D2
Support C2M [™] and CMF SiC MOSFET	Support C3M™, C2M™ and CMF SiC MOSFET
Less immune to EMI noise	More immune to EMI noise
Large form factor	Small form factor
+20/-5 V _G s output	+15/-3.3V V _G s output
Two isolated power supplies	Single isolated power supply






Figure 3: Difference between CRD-001(left) and CGD15SG00D2 (right)

3. Block Diagram

The block diagram of the CGD15SG00D2 gate driver board for Wolfspeed's generation 3 SiC MOSFET is illustrated in Figure 4. It consists of an opto-coupler (U1), a gate driver integrated circuit (U2) and an isolated power supply (X1). The opto-coupler (U1) from Silicon Laboratories Inc. (P/N: Si826BCD) gets an input of pulse width modulation (PWM) signals and provides a high common mode immunity (35KV/us minimum, 50 KV/us Typical). A filtering capacitor across the opto-coupler input has been provided.

Signal from the output of opto-coupler goes into an IXYS Corporation driver integrated circuit (IC) (U2) (P/N: IXDN609SI) as shown in Figure 4. U2 provides up to 9A of output current with a typical output resistance of 0.8Ω .






Figure 4: Block diagram of CGD15SG00D2

Both U1 and U2 get biasing voltage from an isolated DC/DC (P/N: MEJ2D1209SC) converter (X1) manufactured by Murata Manufacturing Co. Ltd. X1 has an isolation voltage rating of 5.2KV with a very low isolation capacitance of 4pF.

X1 gets 12V input and with the help of a Zener diode (as shown in Figure 7) at the output, X1 gives a dual output of +15 V (turn-on signal) and -3.3 V (turn-off signal). Gate resistors R6 and R7 and a diode D3 (as shown in Figure 7) have been provided for gate turn-on and gate turn-off signals. These gate resistors R6 and R7 are metal electrode leadless face (MELF) 207 packages with a power rating of 0.4W.

To minimize stray inductance and achieve tight coupling, capacitors C10-C12 (as shown in Figure 7) have been placed very close to the source output pin. Specified operating conditions for CGD15SG00D2 gate driver board are shown in Table 2.

Operating Conditions					
Symbol	Parameter	Min	Typical	Max	Unit
Vs	Power Supply Voltage	11	12	12.5	V
V _{iH}	Input threshold voltage HIGH	10		15	V
V_{iL}	Input threshold voltage LOW	0 1		1	V
I _{o_pk}	Output peak current			±9*	Α
P _{o_AVG}	Output power per gate		2		W

Table 2: Specified Operating Conditions of CGD15SG00D2 Gate Driver Board



Operating Conditions					
Symbol	Parameter	Min	Typical	Max	Unit
V _{isol}	Input to output isolation voltage	±1700		V	
dv/dt	Rate of change of output to input voltage	50		V/ns	
W	Weight 9		g		
Тор	• Operating temperature		-35 to 85		°C
Tstor	Storage temperature -40 to 85			°C	

^{*(}Actual peak output current will be limited by gate resistor (default is 10ohms turn-on, 5ohms turn-off))

4. Physical Dimensions

Physical dimensions of Wolfspeed's CGD15SG00D2 gate driver board when fully assembled are 47.6 X 17.8 X 22.8 mm (as shown in Figure 5).




Figure 5: Physical dimensions of CGD15SG00D2 (Units are in Inches) *

5. Electrical Connection Points

Connection points of CGD15SG00D2 are in the form of two headers, J1 and J2 (as shown in Figure 6). Header J1 has connection points IN+, IN-, RTN_IN and VCC_IN. IN+ and IN- can be used for the input of PWM signals while RTN_IN and VCC_IN can be used for the input of a DC/DC Converter. Header J2 has connection points of gate and source that can be used to connect Wolfspeed's generation 3 SiC MOSFET.






Figure 6: Connection points of CGD15SG00D2 gate driver board

6. Schematic Drawing

Detailed schematics are shown in Figure 7.




Figure 7: Schematic of CGD15SG00D2 gate driver board

7. Bill of Materials

Table 3: Bill of Materials

Item	Quantity	Reference	Value	Description	Manufacturer	Part Number
1	3	C1, C8, C11	100n	CAP CER 0.1UF 50V 10% X7R 0603	Samsung	CL10B104 KB8SFNC
2	1	C2	1u	CAP CER 1UF 50V 10% X7R 0805	Samsung	CL21B105 KBFNNNE



Item	Quantity	Reference	Value	Description	Manufacturer	Part Number
3	1	C3	DNP			
4	2	C4, C5	1u	CAP CER 1UF 50V 10% X7R 0603	TAIYO YUDEN	UMK107A B7105KA- T
5	2	C6, C7	2.2U	CAP CER 2.2UF 50V X7R 0805	TAIYO YUDEN	UMK212B B7225KG- T
6	2	C9, C12	4.7u	CAP CER 4.7UF 50V 10% X7R 1206	TAIYO YUDEN	UMK316A B7475KL-T
7	1	C10	10n	10000pF ±10% 50V Ceramic Capacitor X7R	Kemet	C0603C10 3K5RACTU
8	1	D1	3V	DIODE ZENER 3.3V 500MW SOD123	On Semiconductor	MMSZ522 6BT1G
9	1	D2	20V	DIODE ZENER 20V 500MW SOD123	On Semiconductor	MMSZ525 0B-TP
10	1	D3	DIODE	DIODE SCHOTTKY 40V 1A SOD123	Diodes Inc	1N5819H W-7-F
11	1	J1	HEADER 4	CONN HEADER .100 SINGL STR 4POS	Sullins	PBC04SAA N
12	1	J2	HEADER 3	CONN HEADER .100 SINGL STR 2POS	Sullins	PBC02SAA N
13	1	L1	CHOKE CM	common mode choke	TDK	ACM4520- 142-2P- T000
14	2	R1,R2	510	RES 510 Ohm 1/8W 5% 0805	VISHAY	CRCW080 5510RJNE A
15	1	R3	DNP			
16	2	R4,R8	47K	RES 47k 1/10W 5% 0603	VISHAY	CRCW060 347K0JNE A
17	1	R5	2K	RES SMD 2K OHM 1% 1/4W 1206	Panasonic	ERJ- 8ENF2001 V



Item	Quantity	Reference	Value	Description	Manufacturer	Part Number
18	2	R6,R7	10	RES SMD 10 OHM 1% 1W MELF 0207	VISHAY	MMB0207 0C1009FB 200
19	1	U1	SI8261BC D-C-IS	DGTL ISO 5KV GATE DRIVER 6SDIP	Silicon Labs	SI8261BC D-C-IS
20	1	U2	IXDN609SI	IC GATE DVR 9A NON-INV 8- SOIC	IXYS	IXDN609SI
21	1	X1	MEJ2D120 9SC	DC/DC Converter	Murata Recom	MEJ2D120 9SC R12P209D

8. PCB Layout

Good PCB layout practice is essential to drive SiC MOSFETs effectively. Minimizing stray inductance in the gate and source path helps reduce ringing and voltage drops that occur due to L*di/dt. Figure 8 shows the top copper layer of the CGD15SG00D2 gate driver board with the gate driver IC (U2), gate drive resistors (R6&R7) and diode (D3). Figure 9 shows the inner copper layer 1 of Wolfspeed's CGD15SG00D2 gate driver board. On that layer, users can observe that the source connection to gate driver IC (U2) is in the form of a large plane encompassing all of the gate driver output components (i.e., the gate resistors and diode) that sit on the top layer of the PCB. This ensures that the current from the gate driver IC output goes through the gate drive resistors and is ultimately mirrored on inner layer 1 of the PCB to minimize inductance.




Figure 8: Top layer copper






Figure 9: Inner layer 1 copper

Inner layer 2 (as shown in Figure 10) on the secondary side of the creepage slot has a large plane carrying the negative drive voltage (-3V). The bottom copper layer (as shown in Figure 11), also on the secondary side of the creepage slot, has a large plane carrying the positive drive voltage (+15V). The VCC input (+12V) has been placed on two large layers that are on the primary side of the creepage slot (inner layer 1 (+VCC) and inner layer 2 (VCC_RTN)).




Figure 10: Inner layer 2 copper




Figure 11: Bottom layer copper

9. Revision History

Date	Revision	Changes
April 2018	Rev B	
January 2024	3	Branding and formatting updates



10. Appendix

<u>Modification Instructions of Wolfspeed's CGD15SG00D2 gate driver board to make it</u> <u>compatible with Wolfspeed generation1 and generation2 SiC MOSFETs</u>

Wolfspeed C2M[™] and CMF SiC MOSFETs have different gate drive requirements than Wolfspeed's C3M[™] SiC MOSFET. For Wolfspeed C2M[™] and CMF SiC MOSFETs, the recommended turn-on voltage is + 20V and the recommended turn-off voltage is -5V. With a few modifications, Wolfspeed's CGD15SG00D2 gate driver board can be used to drive Wolfspeed C2M[™] and CMF SiC MOSFETs.

These modifications are as follows:

- Biasing input (VCC) (as shown in Figure 7) needs to be set at 15V instead of 12V.
- The main isolated power supply (X1) needs to be replaced with another power supply that accepts 15VDC input and gives +20V and -5V output.
- The 3.3V Zener diode (D1) (as shown in Figure 7) that sets the negative bias voltage must be removed.
- The output protection Zener diode (D2, 20V) of isolated power supply (X1) must be replaced by a higher voltage Zener diode (27V) so that it cannot clamp the higher output voltage of the new X1 (25V) during normal operation.
- Resistor R3 (0 ohms) should be populated on the board to connect the common terminal of X1 to the source connection of the driver.
- Resistor R5 is used in the CGD15SG00D2 gate driver board to setup 3.3V negative bias voltage but in Wolfspeed's C2M[™] and CMF SiC MOSFET gate driver board configuration, resistor R5 must be removed (or it may be damaged by the -5V output).

The modifications are summarized below.

Table 4: Design Modifications of Wolfspeed's CGD15SG00D2 Gate Driver Board

Reference	Location	Remove	Populate
			MGJ2D152005SC (Murata)
X1	Тор	MEJ2D1209SC	or
			RKZ-152005D (Recom)
D1	Bottom	MMSZ5226BT1G	-
D2	Bottom	MMSZ5250B-TP	MMSZ5254B-TP
R3	Bottom	-	0805 0ohm jumper
R5	Bottom	2kohms	-



11. Important Notes

Purposes and Use

Wolfspeed, Inc. (on behalf of itself and its affiliates, "Wolfspeed") reserves the right in its sole discretion to make corrections, enhancements, improvements, or other changes to the board or to discontinue the board.

THE BOARD DESCRIBED IS AN ENGINEERING TOOL INTENDED SOLELY FOR LABORATORY USE BY HIGHLY QUALIFIED AND EXPERIENCED ELECTRICAL ENGINEERS TO EVALUATE THE PERFORMANCE OF WOLFSPEED POWER SWITCHING DEVICES. THE BOARD SHOULD NOT BE USED AS ALL OR PART OF A FINISHED PRODUCT. THIS BOARD IS NOT SUITABLE FOR SALE TO OR USE BY CONSUMERS AND CAN BE HIGHLY DANGEROUS IF NOT USED PROPERLY. THIS BOARD IS NOT DESIGNED OR INTENDED TO BE INCORPORATED INTO ANY OTHER PRODUCT FOR RESALE. THE USER SHOULD CAREFULLY REVIEW THE DOCUMENT TO WHICH THESE NOTIFICATIONS ARE ATTACHED AND OTHER WRITTEN USER DOCUMENTATION THAT MAY BE PROVIDED BY WOLFSPEED (TOGETHER, THE "DOCUMENTATION") PRIOR TO USE. USE OF THIS BOARD IS AT THE USER'S SOLE RISK.

Operation of Board

It is important to operate the board within Wolfspeed's recommended specifications and environmental considerations as described in the Documentation. Exceeding specified ratings (such as input and output voltage, current, power, or environmental ranges) may cause property damage. If you have questions about these ratings, please contact Wolfspeed at forum.wolfspeed.com prior to connecting interface electronics (including input power and intended loads). Any loads applied outside of a specified output range may result in adverse consequences, including unintended or inaccurate evaluations or possible permanent damage to the board or its interfaced electronics. Please consult the Documentation prior to connecting any load to the board. If you have any questions about load specifications for the board, please contact Wolfspeed at for assistance.

Users should ensure that appropriate safety procedures are followed when working with the board as serious injury, including death by electrocution or serious injury by electrical shock or electrical burns can occur if you do not follow proper safety precautions. It is not necessary in proper operation for the user to touch the board while it is energized. When devices are being attached to the board for testing, the board must be disconnected from the electrical source and any bulk capacitors must be fully discharged. When the board is connected to an electrical source and for a short time thereafter until board components are fully discharged, some board components will be electrically charged and/or have temperatures greater than 50° Celsius. These components may include bulk capacitors, connectors, linear regulators, switching transistors, heatsinks, resistors and SiC diodes that can be identified using board schematic. Users should contact Wolfspeed at forum.wolfspeed.com for assistance if a board schematic is not included in the Documentation or if users have questions about a board's components. When operating the board, users should be aware that these components will be hot and could electrocute or electrically shock the user. As with all electronic evaluation tools, only qualified personnel knowledgeable in handling electronic performance evaluation, measurement, and diagnostic tools should use the board.



User Responsibility for Safe Handling and Compliance with Laws

Users should read the Documentation and, specifically, the various hazard descriptions and warnings contained in the Documentation, prior to handling the board. The Documentation contains important safety information about voltages and temperatures.

Users assume all responsibility and liability for the proper and safe handling of the board. Users are responsible for complying with all safety laws, rules, and regulations related to the use of the board. Users are responsible for (1) establishing protections and safeguards to ensure that a user's use of the board will not result in any property damage, injury, or death, even if the board should fail to perform as described, intended, or expected, and (2) ensuring the safety of any activities to be conducted by the user or the user's employees, affiliates, contractors, representatives, agents, or designees in the use of the board. User questions regarding the safe usage of the board should be directed to Wolfspeed at forum.wolfspeed.com.

In addition, users are responsible for:

- Compliance with all international, national, state, and local laws, rules, and regulations that apply to the handling or use of the board by a user or the user's employees, affiliates, contractors, representatives, agents, or designees.
- Taking necessary measures, at the user's expense, to correct radio interference if operation of the board
 causes interference with radio communications. The board may generate, use, and/or radiate radio
 frequency energy, but it has not been tested for compliance within the limits of computing devices
 pursuant to Federal Communications Commission or Industry Canada rules, which are designed to
 provide protection against radio frequency interference.
- Compliance with applicable regulatory or safety compliance or certification standards that may normally be associated with other products, such as those established by EU Directive 2011/65/EU of the European Parliament and of the Council on 8 June 2011 about the Restriction of Use of Hazardous Substances (or the RoHS 2 Directive) and EU Directive 2002/96/EC on Waste Electrical and Electronic Equipment (or WEEE). The board is not a finished product and therefore may not meet such standards. Users are also responsible for properly disposing of a board's components and materials.

No Warranty

THE BOARD IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE, WHETHER EXPRESS OR IMPLIED. THERE IS NO REPRESENTATION THAT OPERATION OF THIS BOARD WILL BE UNINTERRUPTED OR ERROR FREE.

Limitation of Liability

IN NO EVENT SHALL WOLFSPEED BE LIABLE FOR ANY DAMAGES OF ANY KIND ARISING FROM USE OF THE BOARD. WOLFSPEED'S AGGREGATE LIABILITY IN DAMAGES OR OTHERWISE SHALL IN NO EVENT EXCEED THE AMOUNT, IF ANY, RECEIVED BY WOLFSPEED IN EXCHANGE FOR THE BOARD. IN NO EVENT SHALL WOLFSPEED BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL LOSS OR DAMAGES OF ANY KIND, HOWEVER CAUSED, OR ANY PUNITIVE, EXEMPLARY, OR OTHER DAMAGES. NO ACTION, REGARDLESS OF FORM, ARISING OUT OF OR IN ANY WAY CONNECTED WITH ANY BOARD FURNISHED BY WOLFSPEED MAY BE BROUGHT AGAINST WOLFSPEED MORE THAN ONE (1) YEAR AFTER THE CAUSE OF ACTION ACCRUED.



Indemnification

The board is not a standard consumer or commercial product. As a result, any indemnification obligations imposed upon Wolfspeed by contract with respect to product safety, product liability, or intellectual property infringement do not apply to the board.